
無線通訊系統 (Wireless Communications Systems)

國立清華大學電機系暨通訊工程研究所

蔡育仁

台達館 821 室

Tel: 62210

E-mail: yrtsai@ee.nthu.edu.tw

Prof. Tsai

課程要求

- Required Prior Knowledge: **Signals & Systems; Probability; Communication Systems**
- Homework: 30%
- Midterm Exam: 35%
- Final Exam: 35%
- Web Site: <https://nyquist.ee.nthu.edu.tw/WCS.html>
 - Password: COM5170WCSys20240903
- Textbook: Gordon L. Stüber, Principles of Mobile Communication, **Second/Third/Fourth** Edition
- 助教： TWNTHUCOM5170@gmail.com

Contents


- **Chapter 1: Introduction**
- **Chapter 2: Propagation Effects**
- **Chapter 3: Physical Layer Technologies for Wireless Communication Systems**
- **Chapter 4: Radio Network Planning Technologies for Wireless Communication Systems**

Contents

- **Chapter 1: Introduction**
 - Multiple Access and Duplex Methods
 - Cellular Concept & Frequency Reuse
 - Antenna Radiation Pattern
 - Radio Propagation
 - Spectral Efficiency

Ch 1. Multiple Access Methods

- **FDMA:** Frequency Division Multiple Access
- **TDMA:** Time Division Multiple Access
- **CDMA:** Code Division Multiple Access




Prof. Tsai

5

Ch 1. Cellular Concept & Frequency Reuse


- $N = i^2 + i \times j + j^2$, $i \geq 0, j \geq 0$, i and j should not be zero at the same time




Prof. Tsai

6

Ch 1. Antenna Radiation Pattern




Ch 1. Radio Propagation



Ch 1. System Performance and Outage

- Outage probability:

- For thermal noise (TN): $O = \Pr(\Gamma < \Gamma_{th})$
- For co-channel interference (CCI): $O = \Pr(\Lambda < \Lambda_{th})$



Prof. Tsai

9

Ch 1. Spectral Efficiency


- The capacity of the AWGN channel is

$$C_{AWGN}(P, W) = \log \left(1 + \frac{P}{N_0 W} \right) = \log(1 + SNR) \quad \text{bits/s/Hz}$$


- where $SNR = P/(N_0 W)$

- η_T : **trunking efficiency**

- Channel assignment
- Trade-off between QoS
- Erlang B formula



Blocking Prob. $B(\rho, m) = \frac{\rho^m}{m! \sum_{k=0}^m \frac{\rho^k}{k!}}$



Prof. Tsai


10

Contents

- **Chapter 2: Propagation Effects**



- Propagation Modeling
- Frequency-Non-Selective (Flat) Multipath Fading
- Frequency-Selective Multipath Fading
- Laboratory Simulation
- Shadowing
- Path Loss
- MIMO Channel Model

Ch 2. Multipath Propagation




Ch 2. Freq.-Selective/Non-selective Fading

- **Frequency-selective multipath fading:**
 - The frequency components may experience different random attenuation and phase shift
 - Significant distortion $\Rightarrow$ ISI, equalization or RAKE is need
- **Frequency-non-selective multipath fading:**
 - All the frequency components experience the same attenuation and phase shift
 - Almost no ISI




Ch 2. Path Loss and Shadowing





Ch 2. Laboratory Simulation

- Jack's Method



Ch 2. MIMO Channel Models

- A MIMO (Multiple-Input and Multiple-Output) system is one that consists of multiple transmit and receive antennas.
- For a system consisting of N_t transmit and N_r receive antennas, the channel can be described by the $N_r \times N_t$ matrix.



Contents

- **Chapter 3: Physical Layer Technologies for Wireless Communication Systems**


- Modulation Schemes
- Digital Signaling on Flat Fading Channels
- Diversity Techniques
- Transmit Diversity
- Precoding
- Equalization
- Random Access Techniques

Ch 3. Modulation Signal


- First generation systems:
 - **FM modulation** (AMPS, TACS, NMT)
- Second generation systems:
 - $\pi/4$ -**DQPSK** (IS-136, PDC, PHS)
 - **GMSK** (GSM, DCS1800, DECT)
- Third generation systems:
 - CDMA – **QPSK/Offset QPSK** (cdma2000, WCDMA)
- Fourth generation systems:
 - OFDM – **BPSK, QPSK, 16-QAM, 64-QAM** (WiMAX, LTE)
- Fifth generation systems:
 - OFDM – ..., **256-QAM, 512-QAM, 1024-QAM**

Ch 3. Diversity Techniques

- Diversity is one very effective solution for combat fading:
 - Provide the receiver with multiple faded replicas of the same information signal
 - Let p denote the probability that the instantaneous signal-to-noise ratio is below some critical threshold on a particular diversity branch
 - p^L is the probability that the instantaneous signal-to-noise ratio is below the same critical threshold on L diversity branches




Ch 3. Space-Time Transmit Diversity




Ch 3. Precoding

- **Precoding** is a modification of a sequence of signals (symbols) before transmission to meet a specific goal/requirement.
- There are various purposes for using precoding in wireless transmissions
 - To decrease the envelope variations of the transmitted signals
 - To mitigate the inter-symbol interference induced by channels
 - To achieve radio resource mapping for different signals
 - For diversity reception
 - For multiple access
 - For mutual interference cancellation




Ch 3. Equalization

- The adaptive equalization is a technique used to mitigate the combined effect of ISI and noise
- Two broad categories of equalizers:
 - Symbol-by-symbol equalizers
 - Sequence estimators



Ch 3. Random Access Techniques

- In a **broadcast channel** (such as a wireless channel), one of the key issue is to determine who gets the right of using the channel when there is **competition** for it.
- In a **synchronous** system (with a **controller**), the **multiple access techniques**, such as TDMA or CDMA, can be applied to prevent/reduce **signal collision** or **mutual interference**.
- In a **asynchronous** system, **random access techniques** should be used.




Contents


- **Chapter 4: Radio Network Planning Technologies for Wireless Communication Systems**
 - Statistics of Co-channel Interference
 - Cellular Coverage Planning
 - Link Quality and Handoff
 - Channel Assignment
 - Wireless Security

Ch 4. Co-channel Interference

- Forward channel:




Ch 4. Cell Coverage Planning




Ch 4. Handoff

- There are three types of handoff in mobile communications systems:
 - Network controlled (NCHO) (AMPS)
 - Mobile assisted (MAHO) (2nd Generation GSM and CDMA)
 - Mobile controlled (MCHO) (low-tier: PACS, DECT, PHS)



Ch 4. Channel Assignment Schemes

- Allocate the available channels to all cells in order to meet the requirements of traffic load and received signal quality for each cell
 - Maximize the offered traffic load
 - Minimize the co-channel interference



Ch 4. Authentication and Roaming

